

Pianoro, (Italy)

25th of May 2017

Requested by: Sasha Seberry

Customer: Croma Coatings

Liquid sample analyzed : AF0618/00 + 10% AH1564/00 (by weight) + 5% (by weight ) of Water .

## Method and Result

The liquid sample was analyzed by method **ISO 11890-2 : 2006** (Gas Chromatography Method, by using an internal standard as a marker compound).

The following solvents were detected, listed in chart below:

COMPONENT	CAS NUMBER	QUANTITY (g/L)
1-METOXY,2-PROPYL ACETATE	108-65-6	17.5
PROPYLENGLYCOL	57-55-6	2.0
DIPROPYLENGLYCOL MONOBUTYL ETHER	29911-28-2	24.3
N-ETHYL, 2-PYRROLIDONE	2687-91-4	0.5
BUTYL DIGLYCOL	112-34-5	0.5



Sherwin-Williams Italy S.r.I. – con socio unico – Export Sales Department Via del Fiffo, 12 - 40065 Pianoro (BO) - Italia – C.P.18 – tel. +39 051 770511 - fax +39 051 770528 export@sayerlack.it - www.sayerlack.com